

STRAIGHTLINE

PERFORMANCE

Installation instructions for Straightline Performance Quick Adjust Clickers.

1. Dissassemble the TRA primary clutch.
2. Unbolt the ramps and remove the stock TRA clicker.
3. Install the new Quick Adjust Clicker as shown below.



When the new pin is installed the threads should protrude at least 1/16 of an inch out of lock nut.