

## 2007-11 Arctic Cat M 1000 Lightweight Muffler 131-103 High Temp Black

## **Installation Instructions**

- 1. Remove the exhaust side body panel from the machine.
- 2. Remove all exhaust springs and clips from the existing muffler. (Set them aside they will be reused.)
- 3. Remove the rubber grommet installed in the existing muffler and install into the Straightline Performance muffler as shown below.
- 4. Install the Straightline Performance muffler into the factory locations.
- 5. Install the clip and springs in the same location that they were removed.





**Note:** Be sure the muffler has no manufacture defects. If the muffler has been run/used there are no warranties for fitment.

**Specifications:** No fuel mapping or clutching is required

Straightline's lightweight mufflers are one of today's standards with low decibel readings and a great low tone. Muffler loses 12+ lbs on your Arctic Cat snowmobile.

Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212 www.straightlineperformance.com

Technical questions please email tech@straightlineperformance.com



Facebook @ straightlineperformanceinc Youtube @ straightlineperfinc Twitter @ straightlineperf



Quantity	Item#	Descriptions	In Box
1	131-103	Muffler	
1		Sticker	

Checked and Packaged By	
-------------------------	--