

STRAIGHTLINE

PERFORMANCE

2003-06 Arctic Cat F6/F7 Lightweight Muffler 131-105 High Temp Black

Installation Instructions

Remove old stock muffler.

Drill a 3/8 inch hole 1" from the side of the heat shield in the belly pan. Center the hole between the 2 rivets holding the plate.



Install the steel spring clip from that supported the stock muffler and install into the new hole from the bottom and spring silencer down.



Install the 1 spring onto the other side of the muffler, and the 2 springs holding the pipe into the silencer. Silencer is ready to run.

Be sure the muffler has no manufacture defects. If the muffler has been run/used there are no warranties for fitment.

STRAIGHTLINE **PERFORMANCE**

BOM: 131-105

Quantity	Item #	Descriptions	In Box
1	IT-131-105	Muffler	
1	11184-02323	Plug	
1		Sticker	
		Checked and Packaged By	

Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212
www.straightlineperformance.com

Technical questions please email tech@straightlineperformance.com



Facebook @ straightlineperformanceinc
Youtube @ straightlineperfinc
Twitter @ straightlineperf