

2010-11 Arctic Cat M8/ Crossfire 8 Lightweight Muffler 131-143 High Temp Black

Installation Instructions

- 1. Remove the exhaust side body panel from the machine.
- 2. Remove all exhaust springs and clips from the existing muffler. (Set them aside they will be reused.)
- 3. Remove the rubber grommet installed in the existing muffler and install into the Straightline Performance silencer as shown below.
- 4. Install the Straightline Performance muffler into the factory locations.
- 5. Install the clip and springs in the same location that they were removed.





Note: Be sure the muffler has no manufacture defects. If the muffler has been run/used there are no warranties for fitment.

Specifications: No fuel mapping or clutching is required

Straightline's lightweight mufflers are one of today's standards with low decibel readings and a great low tone. Muffler loses 12+ lbs on your Arctic Cat snowmobile.

Straightline Performance 15250 Hornsby ST NE Forest Lake, MN 55025 651-466-0212 www.straightlineperformance.com



Quantity	Item #	Descriptions	In Box
1	131-143	Muffler	
1		Instructions	

Checked and Packaged By

Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212 www.straightlineperformance.com

Technical questions can be answered at tech@straightlineperformance.com



Facebook @ straightlineperformanceinc Youtube @ straightlineperfinc Twitter @ straightlineperf