

# **STRAIGHTLINE**

## **PERFORMANCE**

### 2010-12 Polaris Rush/Switchback/Pro-RMK Lightweight Muffler Installation Instructions 132-104

**Parts included: WS-380**

Straightline's lightweight mufflers are one of today's standards with low decibel readings and a great low tone. SPI lightweight muffler will lose 5+ lbs on your Polaris snowmobile. Straightline also offers a single pipe for the same models, check out [www.straightlineperformance.com](http://www.straightlineperformance.com) or your local snowmobile dealer.

#### **Step 1**

Remove all the stock springs that attach the stock muffler to the factory single pipe.

#### **Step 2**

Remove the stock grommet on the bottom of the stock muffler and re-install on the new SPI lightweight muffler the same way as it was removed from the factory muffler.



#### **Step 3**

Remove the bolt shown in the picture with an arrow and install the supplied spring bracket under the bolt. Re-tighten and install muffler. Re-spring the muffler to the pipe and install one of the extra springs to the new location mounted on the chain case. These will be one extra spring not needed for the SPI muffler installation.



Bolt that needs to be removed



New spring clip installed under bolt

Be sure the muffler has no manufacture defects.

If the muffler has been run/used there are no warrantees for fitment.

Jetting Requirements- No Jetting Required

Clutching Requirements-No Clutching Required