

# **STRAIGHTLINE**

## **PERFORMANCE**

### **2003-07 Ski-Doo 500SS/600/800 H.O. Lightweight Muffler 134-109 High Temp Black**

#### **Installation Instructions**

Remove old muffler and keep stock springs. Install new Straightline muffler and use the 2 springs that held the stock pipe on to attach the header of the muffler. Use the back spring to install the one clip near the back of the can to the stock clip next to the chain case. Install the SDI sensor if your machine has one. Be sure the sensor line does not come in contact with any part of the exhaust.

If your machine does not have a SDI sensor please plug the sensor hole with the provided plug. Plug comes with sealer already installed, please do not over tighten plug.

Be sure the muffler has no manufacture defects. If the muffler has been run/used there are no warrantees for fitment.

Jetting Requirements- No Jetting Required

Clutching Requirements-No Clutching Required



# ***STRAIGHTLINE*** **PERFORMANCE**

## BOM

Quantity	Part #	Descriptions	In Box
1	134-109	Muffler	
1	69905	1/4 Pipe Plug (installed on muffler)	
1		Sticker	
1		Directions	

Checked and Packaged By

Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212  
[www.straightlineperformance.com](http://www.straightlineperformance.com)

Technical questions please email [tech@straightlineperformance.com](mailto:tech@straightlineperformance.com)



Facebook @ straightlineperformanceinc

Youtube @ straightlineperfinc

Twitter @ straightlineperf