

STRAIGHTLINE

PERFORMANCE

134-119

2007 Ski-Doo 800R Summit Lightweight Muffler High Temp Black

Installation Instructions

Remove old muffler and keep stock springs. Install new Straightline muffler and use the 2 springs that held the stock pipe on to attach the header of the muffler. Use the back spring to install the one clip near the back of the can to the stock clip next to the chain case. Install the SDI sensor if your machine has one. Be sure the sensor line does not come in contact with any part of the exhaust.

If your machine does not have a SDI sensor please plug the sensor hole with the provided plug. Plug comes with sealer already installed, please do not over tighten plug.

Be sure the muffler has no manufacture defects. If the muffler has been run/used there are no warrantees for fitment.

Jetting Requirements- No Jetting Required
Clutching Requirements-No Clutching Required



STRAIGHTLINE **PERFORMANCE**

BOM

Quantity	Part #	Descriptions	In Box
1	134-119	Muffler	
1	69905	1/4 Pipe Plug (installed on muffler)	
1		Sticker	
1		Directions	

Checked and Packaged By

Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212
www.straightlineperformance.com

Technical questions please email tech@straightlineperformance.com



Facebook @ straightlineperformanceinc

Youtube @ straightlineperfinc

Twitter @ straightlineperf