



**2007 Ski-Doo Summit 800R Single Pipe
134-126 High Temp Black**

Installation Instructions

Remove stock pipe; be sure to keep all stock springs. If you have a ceramic coated pipe there is no need to remove the stock heat shields. When installing the pipe it is best to un-spring the muffler because it is 1+ inch's short. You will have to pull the muffler/Pipe/Y-pipe together, and then re-spring using the stock springs. If you are installing a black satin pipe and installing the heat shields, remove of factory pipe and re-install on Straightline single. Factory covers do not fit the best; this may take some work, to produce the power the pipe sizes and lengths needed to be changed.

Be sure the Straightline single has no manufacture defects. If the pipe has been run/used there are **no warrantees** for fitment.

Jetting Requirements

800R Low Elevation - Carbureted models require a 490 mag/pto (for -20-0 degrees)

Raise Needles .020 PTO and MAG. Stock Pilots

800R High Elevation – No changes needed.

Peak rpm – Peak hp at 8200

Clutching - Straightline recommends adding an Adjustable Pin kit to your snowmobile to help enhance the power. Kits are available from Straightline or your local Ski-doo shop.

Straightline also has complete clutch kits to greatly use the increased HP they are available for your roller secondary.

BOM

Quantity	Item #	Descriptions	In Box
1	134-126	Pipe	
1		Sticker	

Checked and Packaged By

Technical questions can be answered at tech@straightlineperformance.com



Facebook @ straightlineperformanceinc

Youtube @ straightlineperfinc

Twitter @ straightlineperf

**STRAIGHTLINE PERFORMANCE 15250 Hornsby St NE Forest Lake, MN 55025 651-466-0212
www.straightlineperformance.com sales@straightlineperformance.com fax 651-466-0213**