

# **STRAIGHTLINE**

## **PERFORMANCE**

### **Ski-doo Lightweight Muffler 134-134**

#### **2009-18 Ski-doo 600 E-TEC**

#### **Installation Instructions**

1. Remove the existing stock muffler from the machine. On the 600 E-TEC it will be easier to remove the stock single pipe to help aid in the muffler removal.
2. On the stock chassis be sure the rubber rest is in the rear location as shown in picture #1.
3. Next install the spring tab onto the chain case bolt as shown in picture #2.
4. Install the SPI lightweight muffler and 2 stock springs in the correct locations as shown in pictures #2 and 3.
5. Install the 2 springs back onto the stock single pipe and SPI lightweight muffler.



Rubber Rest #1



Rear Spring and Mount Added #2



Front Lower Spring Installed #3

#### **Warranty**

Be sure the Straightline lightweight muffler has no manufacture defects. If the pipe has been run/used there are **no warranties** for fitment.

#### **Specifications**

##### Jetting

Not Required use factory specifications.

##### Clutching

Not Required use factory specifications.

Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212

[www.straightlineperformance.com](http://www.straightlineperformance.com)

**BOM:**

Quantity	Part #	Descriptions	In Box
1	134-134	Muffler	
1	WS-380	Spring Tab	
1		Sticker	
1		Directions	

Checked and Packaged By

Technical questions please email [tech@straightlineperformance.com](mailto:tech@straightlineperformance.com)



**You**Tube



**Facebook @ straightlineperformanceinc**

**Youtube @ straightlineperfinc**

**Twitter @ straightlineperf**