

STRAIGHTLINE **PERFORMANCE**

**Ski-Doo 2003-07 800 H.O. Y-Pipe
134-138 High Temp Black**

Installation Instructions

1. Remove the existing single pipe from the machine.
2. Use a 5mm ball end hex wrench to remove the 8 bolts from the y-pipe.
3. Remove the gaskets from the cylinder and wipe the area clean. (replace if worn)
4. Install the Straightline Performance Y-pipe in the same order the original one was removed.
5. Refer to your service manual for torque specifications.

Warranty

Be sure the Straightline y-pipe has no manufacture defects. If the pipe has been run/used there are **no warranties** for fitment.

Specifications

Jetting

Not Required use factory specifications.

Clutching

Not Required use factory specifications.

Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212 www.straightlineperformance.com

Technical questions please email tech@straightlineperformance.com



Facebook @ straightlineperformanceinc

Youtube @ straightlineperfinc

Twitter @ straightlineperf