



134-163
2010-17 800E-Tec

Parts Included

- 1 Rubber Grommet 21003
- 1 Spring Tab WS-259
- 1 Rivet 41024

Tools suggested

- Spring Tool
- Rivet Gun
- Drill
- 3/16" Drill Bit

Installation Instructions

1. Remove the exhaust temperature sensor and the exhaust springs from the existing muffler set them aside they will be reused.
2. Drill out the rivet for the stock spring tab on the foot well support. (pic 1).
3. Using a rivet gun and rivet attach the new spring tab to the foot well support where the stock spring tab was removed. (pic 1)
4. Install the rubber grommet from the kit over the bottom of the carbon fiber muffler (pic 2).
5. Place the carbon fiber muffler into the factory location and install the three springs that were removed in the first step. (pic3)
6. Install the temperature sensor into the carbon fiber muffler and tighten to factory specifications. (pic 3)



(Pic 1)



(Pic 2)



(Pic 3)

- Be sure the muffler has no manufacture defects. If the muffler has been run/used there are no warranties for fitment.
- Jetting Requirements- No Jetting Required
- Clutching Requirements-No Clutching Required