



**Oil Reservoir Insert
Part# 185-100**



1. Install O-ring around the sleeve.
2. Push sleeve into tank opening.
3. If oil neck is distorted and unable to install the sleeve, heat neck with hair dryer or heat gun for easier installation. Avoid trimming any excess plastic.