



Polaris P-22 Clutch Cover Instructions

(123-171, 123-172, 123-173)

- Remove Clutch side body panel.
- Loosen all (6) M6 primary clutch cover bolts. Only take (3) all the way out. NOTE: Apply pressure to the primary clutch cover when removing the last (3) bolts.
- You will reuse the (6) OEM M6 bolts.
- Install new cover onto clutch.
- Torque the M6 bolts to the manufacture's specification.
- place side panel back on the sled and you are ready to ride.



Disclaimer:

By installing or using this clutch cover, you acknowledge and agree to the following:

Straightline Performance is not responsible for any damage, injury, or loss resulting from the installation or use of this product. This includes, but is not limited to:

- *Mechanical failure or damage to the snowmobile or any other machine*
- *Personal injury to the installer, operator, or others*
- *Property damage of any kind*

Improper installation, modification, or use of this clutch cover can result in equipment failure or unsafe operating conditions. It is the sole responsibility of the installer and/or end user to ensure proper installation and operation in accordance with all applicable safety and maintenance procedures.

By proceeding with the installation, you accept full responsibility for any risks, consequences, or liabilities that may arise.

Do not use impact on clutch cover bolts. Torque to 25 in-lbs (3 N·m)

Check out Straightline Performance at www.straightlineperformance.com.

Tech questions can be handled via e-mail at tech@straightlineperformance.com.