

# **STRAIGHTLINE** **PERFORMANCE**

## 145-112 Polaris, Arctic Cat Single Pipe Temp Sensor Delete/Bypass Plug



### Installation Instructions

#### Step 1: Remove Side Panel

Carefully remove the side panel of your sled to access the muffler area.

#### Step 2: Disconnect Pipe Sensor

Locate the pipe temp sensor harness and disconnect it.

#### Step 3: Install Temp Sensor Delete

Plug the **Temp Sensor Delete** into the sensor harness connector.

#### Step 4: Secure Sensor Probe

Tie up the other end of the sensor probe securely. Make sure it does **not** touch or rub against the muffler or any hot surfaces.

#### Step 5: Reinstall Side Panel

Close the side panel and you're ready to ride.

### BOM

Quantity	Part Number	Part Description
1	145-112	Pipe Temp Delete Plug

Technical questions please email [tech@straightlineperformance.com](mailto:tech@straightlineperformance.com)

Facebook @ straightlineperformanceinc1

Youtube @ straightlineperfinc