



**2010-11 Arctic Cat 800 Y-Pipe
131-138 High Temp Black**

Installation Instructions

1. Remove the stock Y-Pipe; be sure to keep all stock springs, gaskets, and hardware they will be reused.
2. Reinstall the Straightline Performance Y-Pipe in the reverse order of the removal.
3. Using lock tight torque the bolts to factory specifications.
4. Be sure the Straightline Y-Pipe has no manufacture defects. If the pipe has been run or used there will be **No Warranties** for fitment.

Clutching Requirements: No clutching is required.

Operating RPM: 8100-8300

Fuel Mapping: No fuel mapping if only y-pipe is used.

Straightline Performance 15250 Hornsby St Forest Lake, MN 55025 651-466-0212

www.straightlineperformance.com

Technical questions please email tech@straightlineperformance.com



You Tube



Facebook @ straightlineperformanceinc

Youtube @ straightlineperfinc

Twitter @ straightlineperf