



**PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLING KIT.**

**WARNING: BEFORE ANY INSTALLATION OF THIS RSI PRODUCT YOU NEED TO VERIFY YOUR SNOWMOBILE IS OPERATING AND WORKING CORRECTLY. VERIFY STOCK GRIP HEATERS, SWITCHES, HEADLIGHT BULBS, THUMB HEATER, ELECTRONIC REVERSE, AND MULTI FUNCTION GAUGE IS FUNCTIONING NORMALLY. IF ANY OF THESE THINGS ARE NOT FUNCTIONING NORMALLY THEY MUST BE FIXED BEFORE YOU INSTALL THIS RSI PRODUCT.**

### **INSTRUCTIONS FOR USB-C**

#### **DUAL USB POWER CABLE ARCTIC CAT / YAMAHA VIPER**

**1. THE 2 USB CABLE END PORTS NEED TO REMAIN INSIDE A STORAGE DEVICE SUCH AS A BAG OR STORAGE COMPARTMENT. DO NOT MOUNT OUTSIDE A STORAGE COMPARTMENT!!!! ROUTE THE CABLE FROM YOUR ACCESSORY PLUG TO YOUR BAG/STORAGE LOCATION MAKING SURE IT IS SECURED OUT OF THE WAY FROM ANY MOVING PARTS OR HOT PARTS/AREA.**

**2. USING SUPPLIED VELCRO, SECURE CONVERTER BOX SO IT DOES NOT BANG AROUND DURING RIDING.**

**3. ACCESSORY PLUG LOCATION:**

**FOR PRO CLIMB, PRO CROSS, AND YAMAHA VIPER: ROUTE USB CABLE WIRE DOWN TO THE RIGHT SIDE FOOTREST. LOCATE THE ACCESSORY PLUG ABOVE THE RIGHT FOOTREST BEHIND THE PLASTIC BODYWORK AND PLUG THE USB CABLE CONNECTOR INTO THE RUBBER ACCESSORY PLUG.**

*\*NOTE\* The Pro Climb, Pro Cross, and Yamaha Viper models might not power the USB cable at idle. As soon as you apply throttle it will power up and work great.*

**FOR M-SERIES: ROUTE USB CABLE WIRE DOWN TO THE CENTER OF THE STEERING HOOP UNDER HOOD. LOCATE THE RUBBER ACCESSORY PLUG BEHIND THE COVER PLATE AND PLUG USB CABLE CONNECTOR PLUG INTO THE RUBBER ACCESSORY PLUG.**

PHONE: (208-994-6413) E-MAIL: CUSTOMERSERVICE@RSIRACING.COM  
COPYRIGHT 2007-2016 RSI USA ALL RIGHTS RESERVED

**DISCLAIMER:**

**RSI ASSUMES NO LIABILITY FOR MECHANICAL DAMAGE, ENGINE DAMAGE, PERSONAL INJURY OR CRASH DAMAGE OF ANY KIND DO TO IMPROPER INSTALLATION OR USE OF THIS PRODUCT. THE OWNER / OPERATOR OF THE SNOWMOBILE ASSUMES ALL LIABILITY WHEN USING THIS PRODUCT ON THEIR SNOWMOBILE.**