


STRAIGHTLINE PERFORMANCE

Polaris Sportsman Reverse Light Kit

Installation Manual 287-117



Required tools:


Torx T-25 Bit
10mm Socket
Phillips Screwdriver
13/64" Drill Bit (optional)
1/2" Deep-Well Socket
1/2" Combination Wrench
Wire Cutter (trimming zip ties)

Read entire manual before beginning installation process.

Disclaimer: Straightline Performance is not responsible for any damage due to improper installation.



Step 1: Remove Plastics

- 1) Remove center plastic in cargo compartment to access bus bar using T-25 Torx bit.
- 2) Remove clutch side panel (two plastic rivets).



Step 2: Connect Diagnostic Connector & Power Leads

- 1) Remove diagnostic connector cover and plug integrated connector into reverse light wiring harness.
- 2) Connect positive lead to positive terminal of bus bar and negative lead to negative terminal.



Step 3: Mount Controller, Relay, & Fuse

- 1) Secure controller, relay, and fuse. Suggested method is to use drilling template and tighten components with provided machine screws.



Step 5: Route Power to Light

- 1) Run wire and connector along stock wiring harness back to reverse light, while zip-tying the wire as needed.
- 2) Plug in the reverse light you supplied



Step 6: Reinstall Plastics



Straightline Backup Lights
Straightlineperformance.com

287-117

Polaris Sportsman Reverse Light
Tech@straightlineperformance.com

4 of 5

V3



Operation of Reverse Lights

Our controllers have been programmed with a manual override feature. Back-up lights may be turned on without the vehicle in reverse.

- **Fully Automatic When Shifted to Reverse**

1. No programming needed

- **Manual Override Function**

1. Shift the vehicle into neutral
2. Press reverse-override button once. The reverse light will turn on and remain on.

***To turn the light off repeat this procedure.**

Note: If the ignition is turned off while the vehicle is in reverse, or the manual override function is enabled, the lights will remain ON until the ECU enters sleep mode (approximately 30 seconds - 2 minutes depending on vehicle and ECU type).

Part number	Description	Quantity	In box
IT-287-100	60" wire harness, single connector for light, battery terminals, includes relay	1	
IT-287-102	Polaris Diagnostics Adapter Purple and black 8 pin plug on one end and 4 pin white plug on the other.	1	
IT-287-104	Polaris controller	1	
IT-287-110	Blue 4" jumper from harness relay to controller, 2 pin plug on one end flat locking spade on other.	1	
IT-288-105	Bagged female Deutsch connector with pins seal and lock.	1	
Np-209	Zip Ties 6"	10	
	Put blue wire into relay on harness, directions in folder (SPI in house)		
Sticker	stickers	2	
Instructions			

Straightline Backup Lights
Straightlineperformance.com

Polaris Sportsman Reverse Light
Tech@straightlineperformance.com